

ELECTRONICA SOFMEL

<p>CORREAS ELECTROGOMA</p> <p>Audio Video DVD</p> 	<p>RJVC Rodillo JVC</p> 	<p>RAD Rodillo Aiwa derecho</p> 	<p>RAI Rodillo Aiwa izquierdo</p> 
<p>E106C Engranaje E 106 C</p> 	<p>E2 Engranaje N° 2 Largo</p> 	<p>E02 Engranaje N02</p> 	<p>AMIR66 Cabezal stereo 230 ohms, c/largo</p> 
<p>F050 Antena AM Centro Musical</p> 	<p>F080 Antena FM Centro Musical</p> 	<p>RG073 Antena Radiograbador Con base</p> 	<p>RG076 Antena Radiograbador Con base paleta</p> 
<p>Antena radiograb. RG010 10cm RG011 15 cm RG012 18cm RG013 20cm RG016 24cm RG017 26cm</p> 	<p>BG008 Base antena Centrada</p> 	<p>BG007 Base antena Lateral</p> 	<p>SCDS Soporte para CD Aiwa</p> 
<p>TAN Tandem AM 20 x 20</p> 	<p>TAMFM Tandem AM / FM 20 x 20</p> 	<p>CD CD Virgen</p> 	<p>DVD DVD Virgen</p> 

ELECTRONICA SOFMEL

<p>Motor 2 velocidades Giro normal/inverso 6 V – 9 V – 12 V</p> 	<p>Motor con regulación 6 V CW - CCW</p> 	<p>Motor con regulación 9 V CW - CCW</p> 	<p>Motor con regulación 12 V CW - CCW</p> 
<p>RFCP Motor DVD 5.9 volts</p> 	<p>RFCP3 Motor DVD 3 volts</p> 		

Sofmel